


Contractor shall check all dimensions on the work and report any discrepancy to the Landscape Architect before proceeding. All drawings and specifications are the property of the Landscape Architect and must be returned at the completion of the work. This drawing is not to be used for construction until signed by the Landscape Architect.

Key Plan



— — TREE PROTECTION FENCING

PLANTING

LARGE DECIDUOUS TREE

MEDIUM DECIDUOUS TREE

SMALL DECIDUOUS TREE

DECIDUOUS SHRUB
CONIFEROUS SHRUB
GRASSES/PERENNIALS

SODDING

SURFACING

C.I.P. CONCRETE PAVING
UNIT PAVING

AMENITIES

PICNIC TABLE

BIKE RACK


BENCH

City Approval Stamp

Revision

PROPERTY INFORMATION
CITY OF OTTAWA PIN NUMBER 04255-0146





design strategies


1285 WELLINGTON STREET, OTTAWA, ON K1Y 3A8 CANADA T 613.237.2345 NAKDESIGNSTRATEGIES.COM


CCOC 240 PRESLAND 240 PRESLAND, OTTAWA, ON

LANDSCAPE PLAN


Date 2025-01-06
Scale 1:150
Drawn SW
Checked SC
Job No. 24-160

L1.0






LIGHT DUTY UNIT PAVING




 REFER TO SPECIFICATION TO BE CENTERED ON -100MM TAMPER PROOF BOLT USE NON-SHRINK GROUT

**BIKE PARKING** 




SLAB PAVERS ON STONEDUST



1. CONTRACTOR TO PROVIDE ENGINEER STAMPED SHOP DRAWINGS FOR APPROVAL PRIOR TO INSTALLATION


PRECAST RETAINING WALL 6 1:20

MAINTENANCE EDGE 1:10



1.8m HT. PRIVACY FENCE 1:30

Contractor shall check all dimensions on the work and report any discrepancy to the Landscape Architect before proceeding. All drawings and specifications are the property of the Landscape Architect and must be returned at the completion of the work. This drawing is not to be used for construction until signed by the Landscape Architect.



2 Issued for First Submission APR 03/25 JAN 14/25 1 Issued for Client Review No. Description Revision City Approval Stamp

design strategies


1285 WELLINGTON STREET, OTTAWA, ON K1Y 3A8 CANADA T 613.237.2345 NAKDESIGNSTRATEGIES.COM

CCOC 240 PRESLAND 240 PRESLAND, OTTAWA, ON

LANDSCAPE DETAILS

Date 2025-01-06 Scale AS NOTED Drawn SW Checked SC Job No. 24-160

L2.0



PERENNIAL AND ORNAMENTAL GRASS PLANTING

-STAKE BEYOND EDGE OF ROOT BALL USING ONE (1) STAKE 2400mm (MIN) LONG. SECURE TRUNK IN THE DIRECTION OF PREVAILING WIND WITH ARBOR TIES. ARBOR TIE SHALL BE FASTENED IN A MANNER WHICH SUPPORTS TREE, AND ALLOWS FOR SLACK TO PERMIT SOME TRUNK MOVEMENT REMOVE DAMAGED OR OBJECTIONABLE BRANCHES, FOLLOW THE MOST RECENT CANADIAN NURSERY & TRADES ASSOCIATION PRACTICE. DO NOT PRUNE LEADER. PRUNE ONLY WHEN TREE IS ROOT COLLAR TO BE SET 100mm ABOVE FINISHED GRADE -75mm SHREDDED MULCH AS PER SPECIFICATIONS -CONSTRUCT 100mm SAUCER AROUND TREE BASE FINISH GRADE TOPSOIL MIX, LIGHTLYCOMPACT AND WATER WELL TO ELIMINATE AIR POCKETS AND PREVENT SETTLEMENT —CUT AND REMOVE BURLAP AND WIRE BASKET FROM TOP 1/3 OF ROOT BALL WITHOUT DISTURBING ROOTS —SCARIFY SURFACE OF SUBGRADE PRIOR TO PLANTING 150 MIN -MIN 150mm TAMPED MOUND OF PLANTING SOIL TO PREVENT SETTLEMENT 300 300

1. REMOVE STAKE AFTER ONE YEAR OR UNTIL TAKEOVER UNLESS OTHERWISE DIRECTED BY THE LANDSCAPE ARCHITECT.

2. TOPSOIL MIXTURE AND SHREDDED MULCH AS PER SPECIFICATION


CONIFEROUS TREE PLANTING (ONE STAKE W/ARBOR TIES)  $\left(\begin{array}{c} 3 \end{array}\right)_{1:30}$ 

REMOVE DAMAGED OR OBJECTIONABLE BRANCHES, FOLLOW THE MOST RECENT CANADIAN NURSERY & TRADES ASSOCIATION PRACTICE. DO NOT PRUNE LEADER -75mm DEPTH SHREDDED MULCH. PULL BACK MULCH FROM BASE OF SHRUBS. ENSURE THAT MULCH COVERS ALL EXPOSED SOIL WITH SPECIES REMOVE POTS COMPLETELY FROM POTTED STOCK OR CUT AND REMOVE BURLAP AND WIRE FROM TOP 2/3 OF ROOT TOPSOIL MIX, LIGHTLY COMPACT ADD WATER TO WELL TO CUT AND REMOVE BURLAP— ELIMINATE AIR POCKETS AND PREVENT SETTLEMENT AND WIRE BASKET FROM TOP 2/3 OF ROOT BALL —SCARIFY SUBGRADE SURFACE OF PLANTING BED PRIOR TO PLANTING

1. TOPSOIL MIXTURE AND SHREDDED MULCH AS PER SPECIFICATION.

- 2. SHRUBS SPECIFIED BARE ROOT (B.R.) TO BE PLANTED SO THAT ROOTS ARE FULLY EXTENDED IN PLANTING HOLE WITH SOIL MIX BACKFILLED CAREFULLY TO PREVENT ROOT DAMAGE.
- 3. PROVIDE 100mm HIGH EARTH SAUCER AROUND SHRUB BED.
- 4. STAKES TO BE REMOVED AFTER ONE YEAR OR UNTIL TAKEOVER UNLESS OTHERWISE DIRECTED BY LANDSCAPE ARCHITECT.

CONTINUOUS SHRUB BED PLANTING




1. REMOVE STAKE AFTER ONE YEAR OR UNTIL TAKEOVER, UNLESS OTHERWISE DIRECTED BY THE LANDSCAPE

- ARCHITECT. 2. TOPSOIL MIXTURE AND SHREDDED MULCH AS PER SPECIFICATION
- 3. REMOVE TREE WRAP AFTER PLANTING 4. CALIPER TO BE MEASURED AT THE BASE OF TREE AT ROOT BALL.
- DECIDUOUS TREE PLANTING (ONE STAKE W/ARBOR TIES)

1:30

Contractor shall check all dimensions on the work and report any discrepancy to the Landscape Architect before proceeding. All drawings and specifications are the property of the Landscape Architect and must be returned at the completion of the work. This drawing is not to be used for construction until signed by the Landscape Architect.



-		
-		
-		
-		
3		
2	Issued for First Submission	APR 03/25
1	Issued for Client Review	JAN 14/25
No.	Description	Date
Revi	sion	_

City Approval Stamp





1285 WELLINGTON STREET, OTTAWA, ON K1Y 3A8 CANADA T 613.237.2345 NAKDESIGNSTRATEGIES.COM

CCOC 240 PRESLAND 240 PRESLAND, OTTAWA, ON

LANDSCAPE DETAILS

Date 2025-01-06 Scale AS NOTED Drawn SW Checked SC

Job No. 24-160