



1. Under the guidance of a Landscape Architect or Certified Arborist, erect a fence at the critical root zone (CRZ) of trees where the CRZ is established as being 10 centimetres from the trunk of a tree for every centimetre of trunk diameter at breast height. The CRZ is calculated as DBH x 10cm. Refer to the Tree Protection Fence detail. See plan for fence location.
2. When trees to be removed appear on the CRZ of trees to be preserved: cut roots at the edge of the CRZ and grind down stumps after tree removals, do not pull out stumps. Ensure there is not root pulling disturbance of the ground within the CRZ.
3. If roots must be cut, roots 20mm or larger should be cut at right angles with clean, sharp horticultural tools without tearing, crushing, or pulling. Refer to City of Ottawa Specification S.P. F-8011 Tree Protection, Excavation of Root Zone.
4. Hand work only where required within the CRZ, absolutely no machine permitted.
5. Do not place any material or equipment within the CRZ of any tree.
6. Do not attach any signs, notices or posters to any tree.
7. Do not disturb, raise or lower the existing grade within the CRZ without approval.
8. Only dig below when digging within the CRZ of a tree.
9. Do not damage the root system, trunk, or branches or any tree.
10. Ensure that exhaust fumes from all equipment are directed away from any tree canopy.

Legend	
G	Good
F	Fair
P	Poor
VP	Very Poor

DRAWING No.