

PERCENT OF IMPACTED CRZ

Tree 3 - $4.64/15.21=0.305$
Therefore impacted CRZ is 30.5%

Tree 4 - $11.52/38.49=0.299$
Therefore impacted CRZ is 30%

EXISTING TREES


No.	Botanical Name	Common Name	DBH (m)	CRZ (m)	Condition	Owner	Remarks	Recommend
1	<i>Thuja occidentalis</i>	Eastern White Cedar	0.20	2.00	G	Private		Remove
2	<i>Thuja occidentalis</i>	Eastern White Cedar	0.15	1.50	G	Private	Bowed at bottom or trunk	Remove
3	<i>Gleditsia triacanthos</i> var. <i>inermis</i>	Honeylocust	0.22	2.20	G	City		PROTECT
4	<i>Gleditsia triacanthos</i> var. <i>inermis</i>	Honeylocust	0.35	3.50	G	City		PROTECT

Legend

G	Good
F	Fair
P	Poor
vp	Very Poor




LANDSCAPE LEGEND:



TREE PROTECTION NOTES


- The following protection measures must be implemented for retained trees, both on site and on adjacent sites, prior to any tree removal or site works and maintained for the duration of construction on site:
- Under the guidance of a Landscape Architect or Certified Arborist, erect a fence at the critical root zone (CRZ) of trees where the CRZ is established as being 10 centimetres from the trunk of a tree for every centimetre of trunk diameter at breast height. The CRZ is calculated as DBH x 10cm. Refer to the Tree Protection Fence detail. See plan for fence location.
 - When trees to be removed overlap with the CRZ of trees to be preserved: cut roots at the edge of the CRZ and grind down stumps after tree removals, do not pull out stumps. Ensure there is not root pulling or disturbance of the ground within the CRZ.
 - If roots must be cut, roots 20mm or larger should be cut at right angles with clean, sharp horticultural tools without tearing, crushing, or pulling. Refer to City of Ottawa Specification S.P. F-8011 Tree Protection, Excavation of Root Zone.
 - Hand work only where required within the CRZ; absolutely no machinery permitted.
 - Do not place any material or equipment within the CRZ of any tree.
 - Do not attach any signs, notices or posters to any tree.
 - Do not disturb, raise or lower the existing grade within the CRZ without approval.
 - Only tunnel or bore when digging within the CRZ of a tree.
 - Do not damage the root system, trunk, or branches of any tree.
 - Ensure that exhaust fumes from all equipment are directed away from any tree canopy.



NOTE:
THE POSITION OF ALL POLE LINES, CONDUITS, WATERMANS, SEWERS AND OTHER UNDERGROUND AND OVERGROUND UTILITIES AND STRUCTURES IS NOT NECESSARILY SHOWN ON THE CONTRACT DRAWINGS, AND WHERE SHOWN, THE ACCURACY OF THE POSITION OF SUCH UTILITIES AND STRUCTURES IS NOT GUARANTEED. BEFORE STARTING WORK, DETERMINE THE EXACT LOCATION OF ALL SUCH UTILITIES AND STRUCTURES AND ASSUME ALL LIABILITY FOR DAMAGE TO THEM.

No.	REVISION	DATE	BY
3.	ISSUED FOR SITE PLAN APPLICATION	AUG 4/20	RGJ
2.	ISSUED FOR SITE PLAN APPLICATION	DEC 9/19	RGJ
1.	ISSUED FOR COORDINATION	OCT 24/19	RGJ

DESIGN	SCALE
KEW/RGJ	1:150
CHECKED: RGJ	
DRAWN: KEW	
CHECKED: RGJ	
APPROVED: RGJ	



FOR REVIEW ONLY

NOVATECH
Engineers, Planners & Landscape Architects
Suite 200, 240 Michael Cowpland Drive
Ottawa, Ontario, Canada K2M 1P6
Telephone: (613) 254-9643
Facsimile: (613) 254-5867
Website: www.novatech-eng.com

LOCATION
CITY OF OTTAWA
593 LAURIER AVENUE

DRAWING NAME
TREE CONSERVATION REPORT

PROJECT No.
119019

REV # 3

DRAWING No.
119019-L1